


## Instructions



### Battery:

1. Power On Button (turns off automatically),
- 2 .USB Port (Power Out),
3. Charge Indicator,
4. Mini USB Port (Power In)




### Adapters and Cables:


1. USB Out Cable,
2. USB In Cable,
3. Phone Adapters,
4. Universal Adapters




Charge Device with Adapter and USB Out Cable: hold Power On Button 2 seconds.



Charge Device with Manufacturer's USB Cable: hold Power On Button 2 seconds.



Charge Camera Battery w/ Optional Cradle & Adapter: Switch solar panels to 12V (for 7.2V battery)



Point Panels at Sun to Charge Battery: With 4 Watts of solar panels, charges in 7 hours of direct sun.

LEDs	Charge Level
● ● ● ●	76-100%
● ● ● ○	50-75%
● ● ○ ○	25-49%
● ○ ○ ○	<25%

Charge Indicator: Battery LEDs light sequentially when charging; disconnect & hold Power On Button to test charge level.

